#### 1.Notice for use

Thank you for buying WIGAM ETO-4 oil charging and flushing pump.

Please check if your ordered goods in good shipment condition, with the correct accessories.

This manual gives instructions on the correct installation.

It's important that you follow this instructions carefully.

#### 2.Safety precautions



- a) Before carrying out any adjustments or servicing, make sure the installation is disconnected from the power supply
- Don't run this pump without oil
- Don't run in the place with explosion hazard and inflammables

  Don't touch the motor and pump after running long-time to prevent to scald the hand.

#### 3.Product introduction

### 3.1Product profile

ETO-4 electric oil charging and flushing pump is designed according to the feature of compressor oil supplement or change. It's body adopts with integration gear pump.

ETO-4 pump fits all popular brands of refrigeration oil, special for high viscosity oil. Charge the oil very

easy, save the manpower.

## 3.2Technical data

Model	ETO-4	
Voltage	230V 50/60Hz	
Viscosity of oil	<320m2/s	
Motor	180W	
Flow rate	4 l/min	
Max pressure	20 bar	
Outlet port	1/4" SAE	
Weight	5.6kg	

## 3.3Operating instruction

3.3.1. Check before operating (Only qualified service personal should operate this unit, may require the user to be licensed for some countries

Working-spot should have good lighting and atmospheric conditions.

-Make sure the charging refrigerant oil from the oil tank is the same as the type indicated on the nameplate.

-Make sure with the correct voltage as the same as nameplate.

# 3.3.2 Oil charging process

1) Clean the inlet and outlet hose to protect the oil mix, connect to the oil pump, then insert the inlet hose to the tank.

2) Switch on the pump for suction oil and discharge the air from the inlet hose and pump body, then switch off the pump once make sure no air inside. Connect the outlet hose to the oil charging valve of compressor.

-2-



## **ETO-4**

**ENGLISH** 

3) Open the oil charging valve, switch on the oil pump to start to charge the oil.
4) Running the compressor to review if the oil level, pressure and oil temperature are

conditions, and do the adjustment if necessary.

5) Remove the oil tank, oil pump and outlet hose if everything is fine. Wipe out the re and pump. Pack them with sealed plastic bag ,then keep the compressor running ag

## 4. Maintenance

Warning: Before/during checking process, make sure the installation is disconnected supply.

Warning: Don't touch the pump while the unit is very hot after running long-time

To ensure the long-life and performance of oil pump, it should need to use clean pur sure to check first when the oil doesn't be used for a long time.

#### 5. Troubleshooting

Problem	Cause	Solution
Pump isn't operating at all	1.power doesn't reach the pump     2. the voltage isn't correct     3.the thermal protector works     4. the temperature is too low     5. the pump body locked due to the dirt.	1.check the power and sw 2.make sure to keep the i within rated voltage ±5% 3.check the thermal prote 4.increase the invironmen temperature 5. repair the pump
Flow rate is too Small or cann't pump anymore	the inlet hose or filte blocking     the system has the air     the outlet hose block     the oil level is too low     the system pressure is too high     the pump body locked due to the dirt.	1.clean the inlet hose and 2. discharge the air 3. keep the outlet hose un 4. check the inlet hose is tevel or not 5. solve the problem of high
Pump runs with high noise	too low oil level     unreasonable hose size     the dirt inside to pump     the system has the air     pump inner body damaged	check the inlet hose is level or not     dajust the hose size     srepair the pump     discharge the air     repair the pump ,chang
Pump temperature is too high	1.work pressure is more than Max. pump pressure     2. no enough fan cooling     3. the invironment temperature is too high     4.poor ventilation	1.read the manual careful the model     2. check the motor fan ru     3. decrease the invironme temperature     4.improve ventilation

-3-